

Wireless Networks and MAC Protocols



Some Wireless Technologies




Wireless Technology Comparison Chart

Standard	Frequency	Bandwidth	Tx-Power (EIRP)	Range	Goal	Application
802.11 Wlan	2,4 GHz 5 GHz	≤ 600 MBit/s	100 mW	250 m	High Data Rate	Internet Sharing, Media Streaming, File Transfer
802.15.1 Bluetooth	2,4 GHz	$\leq 2,1$ MBit/s	100 mW 2,5 mW 1 mW	100 m 10 m 5 m	Low Power, Ease of Use, Security	Handsfree, Cable Replacement
802.15.4 Zigbee	0,8 GHz 0,9 GHz 2,4 GHz	≤ 20 kBit/s ≤ 40 kBit/s ≤ 250 kBit/s	1 mW	10 m	Ultra-Low-Power, Timing Guarantees	Sensor networks, Remote control



IEEE 802.11 MAC Layer

MAC Architektur:




Distributed Coordination Function (DCF)

- CSMA/CA Protocol
 - Collision Avoidance by random backoff procedure (p-persistent)
 - All Frames are acknowledged, lost Frames are resend
 - Priority Access by Interframe Space (IFS)
- => fair arbitration but no real-time support



Relationship of different IFSs in 802.11




DIFS: DCF Interframe Space
PIFS: PCF Interframe Space
SIFS: Short Interframe Space




IEEE 802.11

Network Types




infrastructure network




Problems

Hidden Terminal Problem





Multiple Access with Collision Avoidance (MACA)



More problems


Exposed Terminal Problem



RTS/CTS to improve throughput



Example of 802.11 RTS/CTS/DATA/ACK Scheme



BO: backoff




Mobile Applications

**Mobile
Sensorbot**

-Battery driven

-Stored energy
varies with size
and price

-Energy
efficiency crucial



**Mobile
Workplatform**

**Static
Sensornode**




Sources of increased energy consumption:

- active wait:** If a node does not know when to expect a message, it must always remain in receive state.
- overhearing:** A node receives a message for which it is not the destination.
Better: switch off the node during this time.
- collisions:** Energy which is used by sending a message during a collision is lost. The respective packet has to be resent completely. Collisions cannot be detected during sending.
- protocol overhead:** Every additional measure like RTS/CTS or an acknowledge scheme increase the protocol overhead.
- Dynamic behaviour:** Unbalanced load increases the probability of collisions (Thrashing).



Multi-Hop vs. Single Hop

- Less Energy
- Less Collisions
- More Reliable



From: Holger Karl, Lecture
Sensor Networks, Uni Paderborn



Exemplary Energy Consumption

AT86RF230: 802.15.4 compatible Radio

-Transmit	3 dBm:	33	mW
-Transmit	1 dBm:	29	mW
-Transmit	3 dBm:	27	mW
-Transmit	-17 dBm:	19	mW
-Receive	:	31	mW
-Standby	:	15,6	mW
-Sleep	:	0,04	mW


AR6102: 802.11b/g compatible Radio

-Transmit	15 dBm:	552	mW
-Transmit	12 dBm:	518	mW
-Receive	:	145	mW
-Sleep	:	0,6	mW



Big Problem: **idle listening**

- ➔ **Rx active power is sometimes greater than Tx active power,**
due to the larger number of signal processing circuits that must be active
- ➔ **It's more power-efficient to blindly transmit than to blindly receive**




Energy efficient protocols try to minimize the time of active listening!

Approaches:

- **Scheduling (TDMA)**
- **activation channel (narrow band additional channel)**
- **Preamble**
- **Adaptive schemes**



Slotted protocols




Example: **S-MAC (Sensor -MAC)** (Ye, Heideman, Estrin)

Nodes are organized in (virtual) clusters, which adopt a common slot format.


Variation **T-MAC (Time-out MAC)**: Adaptively determining the relation between active and sleep periods. If the medium is idle the node can switch to sleep after a short interval.



CSMA



S-MAC




a priori fixed active and sleep intervals

During the activity periods the node must transmit local data + the messages which are relayed in the multi-hop network.

Problem with S-MAC: fixed periods



T-MAC: Time-Out-MAC



Determine the activity and sleep periods adaptively.


T-MAC spans a time-out (active) interval of 15 ms. If no event is detected within this interval it enters the sleep state again. An activation event is given by:

- Alarm of a periodic timer;
- Reception of a message;
- Detection of some communication (also collisions are such events);
- Termination of the own transmission or of an ack.
- The knowledge that a communication by some neighbors has been terminated. (detected by overhearing)

All communication is performed in "bursts" at the start of the active period.



T-MAC: Communication over multiple clusters




Communication between
"virtual clusters" in T-MAC


Messages to relay will be buffered. The size of the buffer determines the upper bounds of activity and sleep periods.




Further improvements: Early Sleeping Problem



Basic Cycle



Early Sleeping Problem.
Node D goes to sleep before node C can send the RTS.



Future Requests to Send (FRTS)


As the FRTS packet would disturb the data packet that follows the CTS, the data packet must be postponed for the duration of the FRTS packet. To prevent any other node from taking the channel during this time, the node that sent the initial RTS (node A in Figure 3.5) transmits a small Data-Send (DS) packet. After the DS packet, it must immediately send the normal data packet. Since the FRTS packet has the same size as a DS packet, it will collide with the DS packet, but not with the following data packet. The DS packet is lost, but that is no problem: it contains no useful information.

J.M. van Dam: An Adaptive Energy-Efficient MAC Protocol for Wireless Sensor Networks
June, 2003



Variations: Low Power Listening

1.)



2.) Sender knows when the receiver is ready. Temporal coordination!

J. Hill, D. Culler: MICA: A wireless platform for deeply embedded networks. IEEE Micro 22(6), Nov. 2002

A. El-Hoiyi: Aloha with preamble sampling for sporadic traffic in ad-hoc wireless sensor networks, IEEE Int. Conf. on Comm. (ICC) New York, Apr. 2002




Low Power protocol: WiseMAC


Christian C. Enz, Amre El-Hoiydi, Jean-Dominique Decotignie, Vincent Peiris (Swiss Center for Electronics and Microtechnology):
WiseNET: An Ultralow-Power Wireless Sensor Network Solution, IEEE Computer, August 2004

WiseMac exploits an optimized form of "Preamble Sampling"

Standard Preamble Sampling



Low Power protocol: WiseMAC




sampling period is piggy-backed in the ack.

In WiseMAC the sender adapts to the receiver's sampling period.

Christian C. Enz, Amre El-Hoiydi, Jean-Dominique Decotignie, Vincent Peiris (Swiss Center for Electronics and Microtechnology):
 WiseNET: An Ultralow-Power Wireless Sensor Network Solution, IEEE Computer, August 2004



Comparing Low Power Protocols; every node has 8 neighbors.



T-MAC:
% of packet loss because of collisions.

WiseMAC:

"With an interarrival time of 100 seconds, the power consumption amounts to as little as 25 microwatts—which translates into more than a five-year lifetime for a single AA alkaline battery."

Christian C. Enz, Amre El-Hoiydi, Jean-Dominique Decotignie, Vincent Peiris (Swiss Center for Electronics and Microtechnology):
WiseNET: An Ultralow-Power Wireless Sensor Network Solution, IEEE Computer, August 2004




IEEE 802.15.4 WPAN

- 2 types of WPAN devices
- Network Topologies
- Architecture

Standard specifies:

- IEEE 802.15.4 PHY Layer
- IEEE 802.15.4 MAC Layer

**ZigBee Alliance:
provides for upper layer
services**



References:

- ➔ IEEE Standard for Information technology—Telecommunications and information exchange between systems—Local and metropolitan area networks
Specific requirements—Part 15.4: Wireless Medium Access Control (MAC) and Physical Layer (PHY), Specifications for Low-Rate Wireless Personal Area Networks (LR-WPANs)
Sponsor: LAN/MAN Standards Committee of the IEEE Computer Society
Approved 12 May 2003. IEEE-SA Standards Board
- ➔ Dvorak, Motorola, IEEE 802.15.4 and Zigbee Overview, 27.09.05
- ➔ Steven Myers, Electrical and Computer Engineering University of Wisconsin Madison, ZigBee/IEEE 802.15.4
- ➔ Jose Gutierrez “IEEE 802.15.4 Tutorial” , Eaton Corporation, Jan. 2003.
- ➔ Marco Naeve “IEEE 802.15.4 MAC Overview” Eaton Corporation, May 2004.



ZigBee vs. Bluetooth

	ZigBee	Bluetooth
Packet size	Small (128 Byte)	Large()
Network size	Large(multi-hop ~10 m)	Small (single-hop $\leq 10\text{m}$)
Number of Nodes	Large(128 in PAN)	Small (8 in PAN)
Security	AES-Encryption	Authentication and Encryption
Complexity of Network Stack	Low	high
Timing	Critical	unimportant
Network Setup	Static and dynamic	dynamic




Provides two services to physical layer management entity (PLME)

– *PHY data service*

- exchange data packets between MAC and PHY

– *PHY management service interface*

- Clear channel assessment (CCA)
 - 3 methods:
 - Energy above threshold,
 - Carrier sense only, or
 - Carrier sense w/ energy above threshold
- Energy detection (ED)
 - Used by network layer (channel selection)
- Link Quality Indication (LQI)
 - Used by higher layers
 - Uses ED and/or SNR estimate



802.15.4 Channel Assignment

Steven Myers
Electrical and Computer Engineering
University of Wisconsin Madison



802.15.4 MAC Layer

Provides two services to the MAC sublayer management entity (MLME)

MAC data service


- **Enables transmission and reception of MAC protocol data units (MPDU) across PHY data service**

MAC management service

- **Beacon management**
- **Channel access**
- **GTS management (GTS:= Guaranteed Time Slot)**
- **Frame validation**
- **ACK frame delivery**
- **Association and disassociation**



Star Topology




● FFD

● RFD



Peer-Peer Topology



Point to point


Cluster tree

● FFD

● RFD



Clustered stars




Clustered stars - for example, cluster nodes exist between rooms of a hotel and each room has a star network for control.



PHY packet format and MAC frame format

Types of MAC Frames:

- Data Frame
- Beacon Frame
- Acknowledgment Frame
- MAC Command Frame




PHY Packet Fields:

- Preamble (32 bits) – synchronization
- Start of Packet Delimiter (8 bits)
- PHY Header (8 bits) – PSDU length
- PSDU (0 to 1016 bits) – Data field



Optional Superframe Structure



Beacon: sent by PAN coordinator in the first slot of the superframe. Contains network information, frame structure and notification of pending node messages.

Contention Access Period (CAP): Communication using slotted CSMA-CA

Contention Free Period (CFP): Guaranteed time slots (GTS) given by coordinator (no CSMA)


Beacon Order (BO): Describes the interval at which the coordinator shall transmit its beacon frames.

Superframe Order (SO): Describes the length of the active portion of the superframe.




Interframe Spacing

Acknowledged transmission



Unacknowledged transmission



$aTurnaroundTime \leq t_{ack} \leq (aTurnaroundTime \text{ (12 symbols)} + aUnitBackoffPeriod \text{ (20 symbols)})$

$LIFS > aMaxLIFSPeriod \text{ (40 symbols)}$

$SIFS > aMacSIFSPeriod \text{ (12 symbols)}$

For (short) frames $\leq aMaxSIFSFrameSize$ use short inter-frame spacing (SIFS)

For (long) frames $> aMaxSIFSFrameSize$ use long inter-frame spacing (LIFS)



Collision Avoidance

Each device has three variables:

NB is the **number of** times the CSMA-CA was required to **backoff** while attempting a current transmission.

CW is the **contention window** length, which defines the number of backoff periods that needs to be clear of activity before a transmission can start.

BE is the **backoff exponent**, which is related to how many backoff periods a device shall wait before attempting to assess the channel.



Arbitration

Slotted CSMA-CA:

Used in superframe structure

Backoff periods are aligned with superframe slot boundaries of PAN coordinator

Used in CAP, must locate boundary of the next backoff period to transmit data


Un-slotted CSMA-CA:

Non beacon enabled network


Backoff periods are not synchronized between devices




Arbitration in Unslotted CSMA



Arbitration in Slotted CSMA



Battery Life Extension (BLE)



Arbitration in Slotted CSMA and Battery Life Extension

- ➔ **The CW is used to safely detect that the a slot is free and no race condition because of slight skew between nodes will lead to collisions.**
- ➔ **The Battery Life Extension property ensures that the "BE" is low ($\min(\text{CW}, \text{macMinBE})$), i.e. if a message has to be sent, it will be sent at the beginning of the superframe. This allows the Turn-Off-Point to be set early to detect that no message is pending.**



Embedded Networks

- o **Introduction**
- o **Models of communication**
- o **Dependability and fault-tolerance**
 - * **Attributes and measures of Dependability**
 - * **Basic techniques of Fault-Tolerance**
- o **Time, Order and Clock synchronization**
- o **The physical network layer**
- o **Protocols for timely and reliable communication**
 - * **Introduction, problem analysis and categories**
 - * **Controller Area Network (CAN-Bus)**
 - * **Time Triggered Protokoll (TTP/C)**
 - * **Byteflight, FlexRay**
 - * **LIN**
- o **Sensornets**
 - * **Requirements for sensor nets**
 - * **Protokols for wireless communication**
 - * **Energy-efficient MAC-protocols**

